

DARF POLY SHIELD INSTALLATION INSTRUCTIONS



UNPACK SHIELDS FROM SHIPPING BOX



OVERLAP PIE SHAPED SECTIONS TO FORM FLAT JOINT



USE (1) PLASTIC FASTENER IN MIDDLE HOLE ON JOINT. ASSEMBLE (6) SECTIONS TO FORM ROUND SHIELD.



POSITION ON RAKE WHEEL



USE CLAMPS TO HOLD ASSEMBLED SHIELD TO WHEEL FRAME



FASTEN TO RAKE WHEEL USING STD. FASTENERS IN TOP AND BOTTOM HOLES ON JOINT. FASTEN OUTSIDE EDGES USING (1) SHORT FASTENER, (2) FLAT WASHERS, AND (1) NUT.